

DI-2108-P USB Data Acquisition (DAQ) System


Communication Protocol

DATAQ Instruments

Although DATAQ Instruments provides ready-to-run WinDaq software with its DI-2108-P Data Acquisition Starter Kits, programmers will want the flexibility to integrate the DI-2108-P in the context of their own application. To do so they want complete control over DI-2108-P hardware, which can be accomplished by using the device at the protocol level. This white paper describes how protocol-level programming of the DI-2108-P is implemented across the Windows and Linux operating systems. We'll define the DI-2108-P's command set and scan list architecture and finish with a description of the DI-2108-P's binary response format.

Device Access

The DI-2108-P can be accessed using the Libusb open source library to control data transfers to and from the instrument via its USB interface in both Windows and non-Windows implementations. When a DI-2108-P is connected to a PC in a Windows implementation the instrument appears in the Device Manager as a "DI-2108-P" under the "libusb-win32 devices" tree:



The following constants apply to the DI-2108-P and must be correctly referenced from your program via Libusb:

- PID = 2109₁₆
- VID = 0683₁₆

DI-2108-P Command Set Overview

The DI-2108-P employs a simple ASCII character command set that allows complete control of the instrument. All of the commands in the following table must be terminated with a carriage return character (0D₁₆) to be recognized by the instrument. Command arguments (if any) are also ASCII, and the command and each argument must be separated by a space character (20₁₆). All commands echo if the instrument is not scanning. Command arguments and responses as always in decimal.

DI-2108-P Command Set	
ASCII Command	Action
Basic communication	
<code>info arg0</code>	Echoes the command and argument with additional information as defined by the argument
<code>ps arg0</code>	Defines communication packet size
Multi-unit Synchronization	
<code>syncget arg0</code>	Sets and retrieves various synchronization timing parameters
<code>syncset arg0</code>	Sets the synchronization timing constant for the device
<code>syncstart arg0</code>	Starts multi-unit synchronized scanning (see the <i>start</i> command to start scanning with a single device)
Scanning	
<code>start arg0</code>	Start single unit scanning (never echoes). See command <i>syncstart</i> for multi-unit, synchronized acquisition
<code>stop</code>	Stop scanning (always echoes)
<code>slist arg0 arg1</code>	Defines scan list configuration
<code>srate arg0</code>	Defines scan rate
Report Modes	
<code>filter arg0 arg1</code>	Defines the report mode (average, min, max, last point) for the specified channel
<code>dec arg0</code>	Defines the decimation factor applied to the specified report mode
Rate measurement	
<code>ffl arg0</code>	Sets the moving average filter length of the rate measurement digital input channel
LED color	
<code>led arg0</code>	Sets the LED to a specified color
Digital I/O	
<code>dout arg0</code>	Outputs the specified data to the digital output port
<code>endo arg0</code>	Enables defined ports as inputs or outputs
<code>din</code>	Returns the value of each digital port that is configured as an input
Reset	
<code>reset arg0</code>	Performs various reset operations

Command Echo Protocol

All commands echo if the instrument is not scanning. Commands will not echo while scanning is active to prevent an interruption of the data stream. In this sense, the *start* command never echoes, and the *stop* command always echoes. In all the following descriptions of DI-2108-P commands, any descriptions and

examples related to a command echo assume that the DI-2108-P is not actively scanning.

Basic Communication Commands

The DI-2108-P command set supports a number of basic command/response items that provide a simple means to ensure the integrity of the communication link between a program and the instrument. These commands elicit simple, yet useful responses from the instrument and should be employed as the programmer's first DI-2108-P communication attempt. If these commands don't work with a functioning DI-2108-P then a problem exists in the communication chain and further programming efforts will be futile until they are resolved.

Responses to this set of commands include echoing the command, followed by a space (20₁₆), followed by the response, and ending with a carriage return (0D₁₆). For example:

```
Command:      info 1          'what model is connected?
Response:     info 1 2109     'command echo, plus connected model PID
```

DI-2108-P Basic Communication Commands	
ASCII Command	Action
info 0	Returns "DATAQ"
info 1	Returns device PID: "2109"
info 2	Returns firmware revision, 2 hex bytes (e.g. 65 ₁₆ = 101 ₁₀ for firmware revision 1.01)
info 3 to info 5	Proprietary internal use for initial system verification
info 6	Returns the DI-2108-P's serial number (left-most 8 digits only; right-most two digital are for internal use)
info 7 to info 8	Proprietary internal use for initial system verification
info 9	Returns the sample rate divisor value of 120,000,000 for the DI-2108-P (see the <i>srate</i> command for details)
ps 0	Make packet size 16 bytes
ps 1	Make packet size 32 bytes
ps 2	Make packet size 64 bytes
ps 3	Make packet size 128 bytes
ps 4	Make packet size 256 bytes
ps 5	Make packet size 512 bytes
ps 6	Make packet size 1024 bytes
ps 7	Make packet size 2048 bytes

The packet size command defines the number of bytes the DI-2108-P sends with each transmission burst. The larger the packet size the more bytes transmitted per burst. Since a packet will not transmit until it is full, you should adjust packet size as a function of both sampling rate and the number of enabled channels to minimize latency when channel count and sample rate are low, and avoid a buffer overflow when sampling rate and channel count are high.

```
Command:    ps 1      'make packet size 32 bytes
Response:   ps 1      'command echo
```

Multi-unit Synchronization Commands

Model DI-2108-P supports synchronized data acquisition across multiple units of the same model. The commands in this group manage various aspects of the synchronization process.

syncget, *syncset*, *syncstart* Commands

These commands in combination manage synchronized sampling across multiple DI-2108-P devices. Each supports a 16-bit, unsigned number (in string format and in the range of "0" to "65535") as either an argument, a returned value, or both as indicated. There is much that goes on in firmware to provide cross-unit synchronization, and a detailed treatment of that process is beyond the scope of this protocol. To simplify the functional application of synchronization we offer only a brief description of each synchronization command, and then pseudocode to show how they are applied.

DI-2108-P Synchronization Command Modes	
ASCII Command	Action
<i>syncget</i> 0	Returns the preferred synchronization timing constant of the device as an unsigned, 16-bit constant (0 to 65535)
<i>syncget</i> 1	Forces the device to re-evaluate the preferred synchronization timing constant, returns the resulting 16-bit, unsigned timing constant for the device, and sets a new value returned by the <i>syncget</i> 0 command. This procedure takes two seconds to complete and is required when the device sends a <i>stop 03</i> error string in the returned data.
<i>syncget</i> 2	Returns the time parameter for the device, which is used by the <i>syncstart</i> command
<i>syncget</i> 3	Returns the active synchronization time constant of the device. If this value is equal for all synced devices, the <i>syncset</i> command is not required. Otherwise an averaged value is used (see pseudocode example.)
<i>syncget</i> 4	Returns two, 32-bit integer sync-quality evaluation parameters.
<i>syncset</i> arg0	Sets the synchronization timing constant for the device represented by <i>arg0</i> as an unsigned, 16-bit constant. It takes one parameter, which is the average of <x>s returned in <i>syncget</i> 0 command from all devices involved in synchronization operation. Ensure that all synchronized devices must have the SAME <i>syncset</i> value.
<i>syncstart</i> arg0	Starts synchronized scanning. <i>arg0</i> is the value returned by the <i>syncget</i> 2 command with bit 10 inverted. The result must be ≥ 1 .

Typical Synchronization Procedure Using Pseudocode

Set up

Pseudocode for two-device, synchronized data acquisition. Command subscripts denote the target device for the command. It is assumed that both devices are connected and communicating. The delay between program line "F = syncget₁ 2" and the last syncstart command must be less than 200 mS.

```
A = syncget1 0
B = syncget2 0
C = (A+B) / 2
D = syncget1 3
E = syncget2 3
if not(D = E = C)
    syncset1 C
    syncset2 C
    delay 1 second
end if
F = syncget1 2
G = (F) XOR (0x0400)
if G = 0 then G = 1
syncstart1 G
syncstart2 G
```

Error handling

Pseudocode example to recover when odd-byte packet (indicating an error state) is received and the data stream has stopped and assuming we have two synchronized devices. In the pseudocode below error\$ is the last seven bytes in the buffer concatenated into a string. The delay between program line "F = syncget₁ 2" and the last syncstart command must be less than 200 mS.

```
if (error$ == "stop 03")
    A = syncget1 1
    B = syncget2 1
    C = (A+B) / 2
    D = syncset1 C
    E = syncset2 C
    delay 1 second
end if
F = syncget1 2
G = (F) XOR (0x0400)
if G = 0 then G = 1
syncstart1 G
syncstart2 G
```

syncget 4 Command

Command syncget 4 can be issued to gain insights to synchronization quality. The command returns two, 32-bit integers:

Command:	syncget 4	'retrieve sync quality
Response:	resp1 resp2	'two quality measures as 32-bit integers

In the above example, two quality measures are returned separated by a space character:

resp1	resp1 applies to USB port performance, the higher the number the worse the performance. The best possible measure for resp1 equals 1. A response greater than 500 means the USB interface is not suitable for synchronization.
resp2	resp2 applies to the tolerance of the sync operation timing, the higher the number the worse the sync timing. A value of 125 or lower is considered very good. A value higher than 10000 indicates very poor sync timing.

Scanning Commands

start Command

Since the start command immediately initiates scanning, the command is never echoed:

DI-2108-P Start Command Modes	
ASCII Command	Action
<code>start 0</code>	Begin scanning: The instrument begins scanning the channels enabled in its scan list through the <i>slist</i> command at a rate defined by the <i>srate</i> command.

Command: `start 0` 'begin scanning
 Response: 'never echoes

stop Command

The protocol's *stop* command terminates scanning. Since the *stop* command terminates scanning, it is always echoed.

Command: `stop` 'stop scanning
 Response: `stop` 'always echoes

slist Command

The DI-2108-P employs a scan list approach to data acquisition. A scan list is an internal schedule (or list) of channels to be sampled in a defined order. It is important to note that a scan list defines only the type and order in which data is to be sampled, not the sampled data itself. The DI-2108-P's scan list supports four types of inputs: Up to eight analog channels; one counter channel; one rate channel; general-purpose discrete inputs. These type definitions may be placed in the DI-2108-P's scan list in any order that satisfies the requirements of the application. The DI-2108-P's scan list is a maximum of 11 elements long, which allows a hardware capacity measurement that's configured to sample all eight analog channels, both the counter and rate channels, and general-purpose digital input ports during one complete scan. Note that any analog, digital input, rate, or counter channel may appear in the scan list only once. *slist* positions must be defined sequentially beginning with position 0.

During general-purpose use each entry in the scan list is represented by a 16-bit number, which is defined in detail in the DI-2108-P Scan List Word Definitions table below. Writing any value to the first position of the scan list automatically resets the *slist* member count to 1. This count increases by 1 each time a new member is added to the list, which must be filled from lowest to highest positions. The first item in the scan list initializes to 0 (analog input channel 0) upon power up. Therefore, upon power up, and assuming that no changes are applied to the scan list, only analog input channel 0 is sampled when scanning is set to active by the start command.

The *slist* command along with two arguments separated by a space character is used to configure the scan list:

slist offset config

offset defines the index within the scan list and can range from 0 to 10 to address a total of eleven possible positions. *config* is the 16-bit configuration parameter as defined in table *DI-2108-P Scan List Word Definitions*. For example, the command *slist 5 10* configures the sixth position of the scan list to specify data from the counter. Assuming that we wish to sample analog channels 2, 4 (on their ± 10 V scale), and 6 (on its ± 2.5 V scale), and the rate, counter, and digital inputs, the following scan list configuration would work:

slist 0 2

slist 1 4

slist 2 518

slist 3 9

slist 4 10

slist 5 8

Note that since the act of writing to scan list position 0 resets the slist member counter, the above configuration is complete upon writing scan list position 5. Further any scan list position (except position 0) may be modified without affecting the contents of the rest of the list.

DI-2108-P Scan List Word Definitions*																
Function	Bit Position															
	15	14	13	12	11	10	9	8	7	6	5	4	3	2	1	0
Analog In, Channel 0	Unused bits =0				Range (see Analog Measurement Range table)				Unused bits =0				0	0	0	0
Analog In, Channel 1													0	0	0	1
Analog In, Channel 2													0	0	1	0
Analog In, Channel 3													0	0	1	1
Analog In, Channel 4													0	1	0	0
Analog In, Channel 5													0	1	0	1
Analog In, Channel 6													0	1	1	0
Analog In, Channel 7													0	1	1	1
Digital In													1	0	0	0
Rate (DI2)	0	0	0	0	Range (see Rate Range table)				0	0	0	0	1	0	0	1
Count (DI3)	0	0	0	0	0	0	0	0	0	0	0	0	1	0	1	0
Ignore	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1

* To be consistent with general programming standards, analog channel numbers begin with 0 instead of 1 as indicated on the product label.

The protocol also supports access to the analog programmable gain feature of the DI-2108-P via four scan list bits per analog channel that are reserved for that purpose:

Analog Measurement Range Table				
Bit Position				Range (V Full Scale)
11	10	9	8	
0	0	0	0	±10
0	0	0	1	±5
0	0	1	0	±2.5
0	0	1	1	0 to 10
0	1	0	0	0 to 5

The protocol also supports a range setting for rate measurements where a count value may be converted to a frequency in Hertz by applying the following formula:

$$rate = \frac{counts + 32768}{65536} \times range$$

"Range" is defined in the following table. Refer to the instrument's specifications for the maximum measurable rate as a function of burst rate.

Rate Range Table (for DI2 connections)				
Bit Position				Range* (Hz)
11	10	9	8	
0	0	0	1	50,000
0	0	1	0	20,000
0	0	1	1	10,000
0	1	0	0	5,000
0	1	0	1	2,000
0	1	1	0	1,000
0	1	1	1	500
1	0	0	0	200
1	0	0	1	100
1	0	1	0	50
1	0	1	1	20
1	1	0	0	10

* Maximum measurable frequency is a function of *srate* (see *srate* Scan Rate Command) and duty cycle of the applied signal:

$srate < 120,000,000 \times ((duty\ cycle) \div 50\%) \div (Range \times 2)$, where duty cycle is the percentage of the cycle for the shorter input state.

```
Command:  slist 0 0      'enabled analog channel 0
Response:  slist 0 0      'command echo
Command:  slist 1 4      'enabled analog channel 4
Response:  slist 1 4      'command echo
Command:  slist 2 1033    'rate channel enabled, 5 kHz range
Response:  slist 2 1033    'command echo
```

***srate* Scan rate Command**

Command *srate* defines a sample rate divisor used to determine scan rate throughput, or the rate at which the DI-2108-P scans through the enabled items in the scan list that you defined with the *slist* command. Note that the sample rate per channel is the throughput rate divided by the number of enabled channels. *srate* is specified with an integer (int) argument (the divisor) within the range of 750 to 65,535 inclusive, and the resulting scan speed throughput is defined by the following equation:

$$\text{Sample rate throughput (Hz)} = 120,000,000 \div (\text{srate} \times \text{dec})$$

This approach results in a throughput rate ranging from 1831.08 to 160,000 Hz when the decimation factor (dec) equals one, or the report mode (See Report Mode Commands section) is last point. The host program may achieve a further reduction in sample rate below 1831.08 Hz by using selective sampling methods whereby every *n*th point is selected as the converted value. For example, a sample throughput of 20 Hz is achieved by applying an integer value of 60,000 to the *srate* command, and further selecting every 100th value from the reported data stream. Every 1000th reading is effectively 2 Hz. Averaging every *n* values on each channel is more difficult but recommended since it reduces noise by a factor of the square root of *n*.

Note that the dividend (120,000,000) used in the above equation can change between data acquisition products. The command *info 9* can be used to determine the value for each product.

Report Mode Commands

The DI-2108-P supports a range of report modes that are selectable per channel. The instrument can acquire and report the last point that was acquired, the maximum or the minimum of a range of values, or the averaged result. The report mode may be defined on a per channel basis using the *filter* command. The *filter* command accepts two arguments of the form:

```
filter arg0 arg1
```

Where: $0 \leq \text{arg0} \leq 7$ and is equal to a specific analog channel number. *arg0* can also equal "*" as a shortcut way to reference all channels.

$0 \leq \text{arg1} \leq 3$:

<i>arg1</i>	
Value	Acquisition Mode
0	Last Point
1	Average
2	Maximum
3	Minimum

A decimation factor (*dec*) may be applied to define the number of samples used per channel by each acquisition mode (except Last Point.) For example, if *dec* has a value of 100 and the *filter* command defines an acquisition mode for a channel as Maximum, one value is reported for every 100 that are acquired, the maximum of the 100 samples. The next acquired 100 values are evaluated and the maximum value is reported, and so on. Setting *dec* to a value of 1 essentially forces the filter's Last Point mode even if Maximum, Minimum, or Average is specified.

When the *filter* command defines the average Acquisition Mode, the *dec* command sets the number of samples used to calculate the average.

```
dec arg0
```

Where: $1 \leq \text{arg0} \leq 512$ sets the number of values used by the report mode defined by the *filter* command.

Sample report and decimation commands and responses:

```
Command: filter * 2      'Set all channels to maximum acquisition mode
Response: filter * 2      'Set all channels to maximum acquisition mode
Command: dec 128          'set the decimation factor to 128
Response: dec 128         'the current decimation factor is 128
```

Rate Measurement Commands

When the rate channel is enabled in the instrument's scan list using the *slist* command, a moving average filter may be applied to smooth readings. The moving average factor is defined by the *ffl arg0* command, where $1 \leq \text{arg0} \leq 64$ and the default value is 32.

Command: `ffl 20` 'set the MA factor to 20

Response: `ffl 20` 'the current MA factor is 20

LED Color Command

The DI-2108-P has a panel-mounted, multi-color LED that is available for general-purpose use. The *led* command accepts one argument that defines the color of the LED, and takes the following form:

`led arg0`

Where:

arg0	Color	arg0	Color
0	Black	4	Red
1	Blue	5	Magenta
2	Green	6	Yellow
3	Cyan	7	White

Command: `led 1` 'set the led color to blue

Response: `led 1` 'the led color is blue

Digital I/O Commands

The protocol supports three commands for digital I/O. The DI-2108-P provides seven digital ports. Each port can be programmed as either an input or an output. A port configured as an output is really a switch that is either on or off to control an external load.

One command (*endo*) defines configuration on a per port basis, input or switch. A second command (*dout*) defines the state of a port's switch if the port is configured as an output. The third command (*din*) reads the state of all ports regardless of I/O configuration.

***endo* command**

`endo arg0`

Where: $0 \leq \text{arg0} \leq 127_{10}$ and maps input/switch configuration to each of seven digital ports. A value of one written to a port configures it as a switch. A value of zero configures the port as an input.

Command: endo 20 'ports D0,D1,D3,D5,D6 as inputs
 'ports D2 and D4 as switches
Response: endo 20 'command echo

dout command

dout arg0

Where: $0 \leq \text{arg0} \leq 127_{10}$ ($0 \leq \text{arg0} \leq 7F_{16}$) and defines the bit state of the 7-bit output port.

Command: endo 20 'ports D0,D1,D3,D5,D6 as inputs
 'ports D2 and D4 as switches
Response: endo 20 'command echo

Command: dout 4 'set D2 switch is on. D4 switch is off
Response: dout 4 'command echo

din command

din

Command: din 'read all port states
Response: din 20 'ports D2 and D4 are set. Others are clear

din does not discriminate between ports configured as inputs or as switches. The command simply returns the state of all ports as a 7-bit value. A port configured as a switch returns the state of the switch. One configured as a digital input returns the applied state.

Reset Command

There is only one reset command used to force accumulated counts to zero:

reset arg0

Where: $\text{arg0} = 1$ to reset the DI-2108-P counter

Command: `reset 1` `'reset the counter`

Response: `reset 1` `'command echo`

Binary Stream Output Format

The DI-2108-P's data output format is a binary stream of one 16-bit word per enabled measurement. In the table below A_x values denote analog channel ADC values, and D_x , R_x and C_x are digital, rate, and counter value inputs respectively.

Binary Data Stream Example (all functions and channels enabled in order)										
Scan list position (measurement)	Word Count	Byte Count	B7	B6	B5	B4	B3	B2	B1	B0
0 (Analog in 0)	1	1	A7	A6	A5	A4	A3	A2	A1	A0
		2	A15	A14	A13	A12	A11	A10	A9	A8
1 (Analog in 1)	2	3	Same as analog in 0							
		4								
2 (Analog in 2)	3	5								
		6								
3 (Analog in 3)	4	7								
		8								
4 (Analog in 4)	5	9								
		10								
5 (Analog in 5)	6	11								
		12								
6 (Analog in 6)	7	13								
		14								
7 (Analog in 7)	8	15								
		16								
8 (Digital in)	9	17	0	0	0	0	0	0	$\overline{D1}$	$\overline{D0}$
		18	0	D6	D5	D4	D3	D2	D1	D0
9 (Rate in)	10	19	R7	R6	R5	R4	R3	R2	R1	R0
		20	R15	R14	R13	R12	R11	R10	R9	R8
10 (Counter in)	11	21	C7	C6	C5	C4	C3	C2	C1	C0
		22	C15	C14	C13	C12	C11	C10	C9	C8

Analog Channel Binary Coding

The DI-2108-P transmits a 16-bit binary number for every analog channel conversion in the form of a signed, 16-bit Two's complement value:

DI-2108-P ADC Binary Coding																	
D ₁₅	D ₁₄	D ₁₃	D ₁₂	D ₁₁	D ₁₀	D ₉	D ₈	D ₇	D ₆	D ₅	D ₄	D ₃	D ₂	D ₁	D ₀	Counts	Voltage*
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	1	32767	9.9997
0	1	1	1	1	1	1	1	1	1	1	1	1	1	1	0	32766	9.9994
...																	
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	1	0.0003
0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0
...																	
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	1	-32767	-9.9997
1	0	0	0	0	0	0	0	0	0	0	0	0	0	0	0	-32768	-10.0

* Assuming the DI-2108-P is programmed for the ± 10 V full scale range.

Applied voltage as a function of ADC counts has the following relationships depending upon both measurement range and mode (unipolar or bipolar):

Bipolar measurement ranges:

$$volts = full\ scale\ range \times \frac{counts}{32768}$$

Unipolar measurement ranges:

$$volts = full\ scale\ range \times \frac{counts}{65536}$$

Rate and Count Channel Binary Coding

If enabled the DI-2108-P delivers 16-bit count and rate data. Meaningful information is extracted from the DI-2108-P for these measurements as follows:

$$counter\ value = counts + 32768$$

$$rate = \frac{counts + 32768}{65536} \times range$$

Where: *counts* is the 16-bit value provided by the DI-2108-P for the indicated measurement
range is the selected rate measurement range in Hz (see Rate Range Table)

Control

Revision	Date	Description
1.0	January 18, 2017	Original release level